



building from waste

info@prettyplastic.nl
www.prettyplastic.nl
@we_are_prettyplastic

BASIC THIRD INSTALLATION MANUAL

March 2024

INSTALLATION MANUAL

PRODUCT NAME BASIC THIRD

TECHNICAL DATA


HEIGHT	560mm
WIDTH	317mm
THICKNESS	15mm

NUMBER OF TILES PER M ²	6.7
WEIGHT PER TILE	1.9kg
WEIGHT PER M ²	12.7kg

MATERIAL	recycled Polyvinylchlorid (PVC)
----------	---------------------------------

FLAMMABILITY (EN 13501-1:2018)	B-s3, d0
--------------------------------	----------

PRODUCTION TOLERANCES	+/-2%
-----------------------	-------



INSTALLATION MANUAL



PRODUCT NAME BASIC THIRD

PRODUCT

Pretty Plastic tiles are utilized in ventilated facades, catering to both renovation projects and newly constructed facades.

PROCESSING

Pretty Plastic can be cut or drilled without producing any splinters. Tiles can be cut using a jigsaw, circular saw, or handsaw. Collect sawing waste and cutting losses separately to prevent them from being blown away. Make sure to manage these waste materials properly.

APPLICATION

- Pretty Plastic tiles can be installed at angles up to a maximum of 45 degrees, given the application of a water-retaining layer.
- It's important to note that the structural engineer holds the final responsibility for ensuring the accurate installation and application of the tiles.

PAINTING

Please note that Pretty Plastic tiles are not intended for painting.

MAINTENANCE

Pretty Plastic is maintenance-free and can be cleaned using household cleaning products.

INSTALLATION

Pretty Plastic tiles should be attached to a wall with an underlying wooden structure composed of wooden slats (C18); these should have a minimum dimension of 24x48mm or 28x45mm, which are commonly available sizes in the EU.


Secure each tile to the slat construction using screws. We recommend using SPAX Universal Screw 25/45x4mm or an equivalent product for this purpose.

- Install horizontal slats with a 500 mm spacing on a vertical substructure set 600 mm apart.
- The vertical substructure creates a ventilated cavity.
- Include ventilation openings at both the top and bottom ends of the facade.
- Secure each tile using either one or three screws, depending on the building's height and the local wind load according to NEN-EN 1991-1-4 . Check our technical guide for detailed information.
- Maintain a 10 mm seam for a center-to-center distance of 300 mm.
- For corner ends and window frame connections, refer to the proposed detail drawings for various possible solutions.


INSTALLATION MANUAL

PRODUCT NAME BASIC THIRD


WOODEN STRUCTURE



TILE PATTERN



INSTALLATION MANUAL




Pretty
Plastic


building from waste

PRODUCT NAME BASIC THIRD

MEASURE PLAN




SCREW POSITION



INSTALLATION MANUAL


PRODUCT NAME BASIC THIRD

STEP 1



1. Construct a wooden framework in front of the insulated wall.

STEP 2





2. Start from the bottom left corner, securing a single screw to the right side at the tile's bottom. Each tile requires only one screw. Use the tab on the back of the tile for easy hanging onto the wood structure. Proceed by installing the tiles sequentially to the right in a row.


INSTALLATION MANUAL

PRODUCT NAME BASIC THIRD

STEP 3



3. After finishing with the first row, move to the next. Use one screw at the bottom right to hold three tiles together.



POSITION OF SCREWS

Screw position 1: Attach the screw directly to the tile.


Screw position 2: Automatically screwed when fastening the upper left tile.

Screw position 3: Automatically screwed when fastening the tile above.

INSTALLATION MANUAL


PRODUCT NAME BASIC THIRD

DESIGN SUGGESTIONS




OPTION A

- Begin from the middle, ensuring two identical corner endings.
- Ideal when utilizing a corner profile



OPTION B

- Start from a corner using a complete tile to achieve a tidy corner.
- Adjust the seam by 3mm more or 10mm less if necessary.



WINDOW CORNERS

Try to cut the tiles in a single direction rather than sawing a corner.

standard seam:
300mm * x - 10mm


larger seam:
301mm * x - 11mm
302mm * x - 12mm
303mm * x - 13mm

smaller seam:
299mm * x - 9mm
298mm * x - 8mm
297mm * x - 7mm
296mm * x - 6mm
295mm * x - 5mm
294mm * x - 4mm
293mm * x - 3mm
292mm * x - 2mm
291mm * x - 1mm
290mm * x


INSTALLATION MANUAL

PRODUCT NAME BASIC THIRD

DESIGN SUGGESTIONS



When cutting the tile on the left side, add an extra screw along screw line 2. This screw will go through just one tile instead of three, while still keeping the tile securely in three positions.




When cutting the tile on the right side, screw position 1 won't work. The tile will be secured in two positions: at screw 2 and position 3 along the line of position 2.

INSTALLATION MANUAL


PRODUCT NAME BASIC THIRD

PATTERN OPTIONS




standard pattern
tile bond
300x500mm

use pre-made holes




alternative pattern
uneven stretcher bond
300x500mm

use pre-made holes
and top markers for tile
alignment



alternative pattern
stretcher bond
300x500mm


use pre-made holes
and top markers for tile
alignment




INSTALLATION MANUAL

PRODUCT NAME BASIC THIRD


VERTICAL DISTRIBUTION OPTIONS



standard pattern
500mm



smallest pattern
300mm
(more tiles per m² are needed)




- < screw position 300mm
- < screw position 400mm
- < standard screw position 500mm



INSTALLATION MANUAL

PRODUCT NAME BASIC THIRD


CORNER SOLUTION



For a neat corner, cut the tile along the angled line marked on the back. This allows two tiles to fit seamlessly together (refer to detail 4 for visual guidance).



Angled lines are located on the back of the tile to guide the sawing line.



INSTALLATION MANUAL

PRODUCT NAME BASIC THIRD



Pretty
Plastic

building from waste


principle details

INSTALLATION MANUAL

PRODUCT NAME BASIC THIRD

D1 - TOP CONNECTION WINDOW FRAME

SCALE 1:5




INSTALLATION MANUAL

PRODUCT NAME BASIC THIRD

D2 - BOTTOM CONNECTION WINDOW FRAME

SCALE 1:5




INSTALLATION MANUAL


PRODUCT NAME BASIC THIRD

D3 - WINDOW FRAME HORIZONTAL

SCALE 1:5



INSTALLATION MANUAL




Pretty
Plastic

building from waste


PRODUCT NAME BASIC THIRD

D4 - CORNER CONNECTION

SCALE 1:5



INSTALLATION MANUAL



Pretty
Plastic

building from waste

PRODUCT NAME BASIC THIRD

D5 - CORNER CONNECTION

SCALE 1:5

